


VF215 Instruction manual

Serial number: from 03001




Congratulations on your Duun VF215 snow blower.

All Duun tractor operated machines have been engineered and tested in close cooperation with representative users to produce functionally safe and user-friendly machines.

Please read this instruction manual before using the machine.

Good luck!



Machine identification

Serial number and manufacturer are indicated on badge (A)

Register serial number and delivery time as indicated.

Always specify serial number when requesting service for the machine.

The machine is CE-marked (B). This marking confirms that the machine has been manufactured in conformity with EU Directive Machinery.

Serial number

Time of delivery (month/year)

CONTENT


MACHINE IDENTIFICATION	2
SAFETY	4
WARRANTY TERMS	7
TECHNICAL DATA	8
PREPARATION FOR USE	11
CONNECTION	12
SERVICE AND MAINTENANCE	14
SHEAR – BOLT COUPLINGS	15
OPERATIONAL RISKS	15
PRACTICAL USE	15
DISCONNECTION	15
DECLARATION OF CONFORMITY	16

SAFETY

All operators, mechanics and the owner must always work carefully with agricultural machinery. Read and observe safety instructions in this instruction manual.




Be particularly aware of warning signs with this symbol, it marks measures that must be carried out in order to avoid accidents. The symbol appears in the instruction manual and on warning signs on the machine.



1. Instruction manual

All operators, mechanics and the owner must be well acquainted with the instruction in this instruction manual before the machine is taken into use.




2. Safety of the surroundings

Be very careful when other people or animals are near the machine or tractor. Never start the machine when there are people or animals close to it, also never stand between the tractor wheels and the machine!



3 Safe connection and use

Do not allow anyone to stay between the machine and the tractor when the machine is connected to the tractor. The same applies during the use of the machine. Make sure that the connection is carried out in a safe manner. By automatically connecting with a triangle or HMV, the hydraulic hoses are connected before the start of work. Connecting with draw bolts, secure the drawbar connection with lunch pins before the hydraulic connection and start operation.



4. Safety in case of interruptions and maintenance

Remember always to stop the tractor's engine and remove the ignition key before you lubricate, adjust, clean, or carry out repairs. This is to secure that the tractor does not start before you have completed the operation.



5. Power transmission shaft


The tractor is disengaged and the handbrake is applied before the shaft is connected to the tractor's PTO. The maximum power output speed is 540 rpm. The drive shafts are always to be equipped with original protection covers. **Damaged and worn covers are to be replaced immediately!**

Make sure that all covers for the shaft are in good condition and correctly fitted. Never start the machine when this is not in order. The locking chains for the plastic covers are always to be fixed to the appropriate brackets in order to prevent the covers to rotate. The covers must be lubricated according to the specified interval.




6. Rotating parts – high risk of injury

The rotating parts of the machine can cause major damage to body parts that come into contact with them. Do not allow anybody to stay in the work area when a machine is in operation.



7. Hydraulic high fluid pressure

Be careful when you work with hydraulics. Wear eye protection and gloves. Hydraulic oil under high pressure may penetrate the skin and cause serious infections. See a doctor if you have sustained an injury. Make sure no one is close by when performing hydraulic functions.



8. Risk of crushing at marked points

Pay special attention to clamping risk at points marked for this.



9. Clamping risk when adjusting

When adjusting the support wheels, make sure that you do not stand with your feet under the wear steel.

Always lower the machine to safety rest at ground level when it needs to be parked.

Never work under a lifted device unless it is mechanically secured against coming down.

Before startup after servicing make sure all tools have been removed and brought into place.

Do not work in clothing that can be retracted into moving parts of the machine (e.g. scarves, wide coats).

Wear hearing protection if the machine has annoying or damaging noise levels.

Before the machine is raised or lowered, make sure that no person is near or touching the machine.

If warning signs are removed during repairs or service, new signs should be installed immediately!

Warranty terms

Duun VF215 has 12 months guarantee against defects in materials and workmanship.

Parts that are not originally manufactured by Duun Industrier as, for example, wheels, hydraulic parts, etc. are subject to these suppliers' guarantees and terms.

In cases where a repair is considered to be covered by the guarantee, the representative must inform the supplier's representatives that the repair is intended executed based on the guarantee. In this context, the following information must be recorded:

- Product name
- The product's serial no. (see the machine identification)
- Date of sale
- The product owner's address, telephone no.

In case of such a repair, the supplier is presented with a claim within 3 weeks after the repair date.

Replaced parts are to be kept until a decision has been made with reference to the claim and the replaced parts are to be forwarded to Duun Industrier as for assessment if so required.



As the employment of the product is beyond our control, we may only guarantee the quality and do not accept liability for the product's general performance.

Duun Industrier as reserves the right to modify the design and specifications and/or make alterations and improvements without notification.


What is not included in the guarantee:

- The guarantee does not cover economic loss as a consequence of interruptions.
- The guarantee does not cover consequential loss due to defects.
- The guarantee does not cover defects or damage caused by misuse and uses that are not in accordance with the instruction manual's specifications and guidelines.

Technical data




Features:	VF215
Weight	450 kg
Width (a)	2150 mm
Maks lengde (b)	1830 mm
Side length (c)	1510 mm
Three-point linkage (d)	655 mm
Working height chassis (e)	800 mm
Max height of outlet spout (f)	1955 mm
Speed of PTO shaft	540 rpm
Bolt fasteners connections are standard	Yes
Number of blades in ejector fan	4
Diameter of fan	700 mm
Power requirement PTO	55hk/40kw
Diameter of right side wear steel	10x100x1310mm
Diameter of left side wear steel	10x100x1310mm
Fastening wear steel.	305 mm
Asseccories:	
Side extension 1m right 1251315	Yes
Side extension 1m left 1251316	Yes
Extra set (pair) of skid pads 1251317	Yes
Hydraulically operated outlet flap 1251118	Yes
PTO	Yes
Triangle coupling 1252637	Yes
HMV coupling 1252638	Yes



Transportation and management before use

Snow blower housing is always lifted with strap attachments as illustrated. Please note that a single snowblower weighs approx. 450 kg. Use lifting equipment suitable for this weight!!



Installation of the ejector spout and drive motor

Bracket with oil motor is unscrewed by loosening 2 pieces of M10 screws. The ejector spout is attached to the hull with 6 m10 screws, washer and lock nut for this. The bracket with the oil motor is fixed in place, the adaptation of this to the "tooth ring" is adjusted with the fastening screw A. It is adjusted so that the spout can rotate easily (clearance approx. 1mm).

Preparation for use

Adjustment of skid pads

The snow blower is placed on a level surface and the skid pads are adjusted so that the wear steels on both sides + the infeed steel in front of the fan housing have clearance above ground level. Too small distance here will cause abnormal wear on both wear steel and feed steel.

Power transmission shafts

Make sure that the PTO shaft is of sufficient length. After any length adjustment, the profile pipes in the shaft must overlap each other by half the pipe length. Any cutting of the shaft is carried out accordance to the instructions for this – the cut point is chamfered inside and out, and the profile tubes are lubricated with grease. Too short a telescopic length on the shaft entails a risk of overloading the tractor's power take-off and the snow blower's bearings.

Please lubricate the power transmission shaft before use.

The shear bolt coupling on the shaft is mounted against the implement. The coupling has a capacity of 4180 nm and in the event of a break in this, a hexagonal screw dim 12 mm qval 8.8 must be used as a breaking pin. The locking chains for the protective covers must always be attached to suitable fasteners to prevent the covers from rotating.

The power transmission shafts are maintained and used according to the attached instruction manual.

Save control of greasing (lubrication)

Check that the warehouses (front and back) are lubricated. Lack of lubrication entails a risk of breakdown. Also, be careful not to "over-lubricate" the bearings as this entails the risk of heat build-up and overheating in the bearing itself. In the case of too little lubrication, water can penetrate (infiltrate) the bearings.

Lubrication of ball bearing

Check that this is lubricated and make sure it is lubricated before use if this is not the case. Too little lubrication causes abnormal wear on the gears and chain.

Lubrication of feeding blade

Check that this is lubricated and make sure it is lubricated before use if this is not the case. Too little lubrication causes abnormal wear on the gears and chain.

Protection of hydraulic hoses

Check the hose connections and that they are not stretched or cut during use. Tighten loose hose connections and secure/fasten the advance of the fittings. Failure to secure hydraulic hoses can lead to leaks and consequential damage to tractors and components.

Connection

Stabilization struts/support struts on tractors must be used.

This is to ensure that the snow blower does not get uncontrolled lateral movements while driving – i.e. goes in the same direction as the tractor all the times.

Make sure no one is standing between the tractor and the machine during connection. Back the tractor up to the snow blower and stop the engine before the lifting arms are mounted in the three-point linkage, or is automatically connected to quick coupling HMV or triangle.

Hydraulic hoses installation. At the same time, check that all hoses are tight and undamaged before starting hydraulic functions. When the tractor engine is stopped, you should ensure that there is no pressure in the hoses by activating the tractor's hydraulic valves.

Pay special attention to the dangers of hydraulic oil under pressure.

Install the power transmission shaft on the PTO with the shear - bolt coupling against the snow blower. A safety chain is attached to the snow blower to prevent the rotation of protective covers.

The power transmission shaft must always have a shear bolt coupling max 2920 nm.


Make sure that the protective covers for the power transmission shaft are undamaged and replace them if they are damaged.

Before connecting the power transmission shaft, secure the following points.

Make sure that the shaft's protective tubes are undamaged and that the two halves of the shaft fit freely into each other. The length of the power transmission shafts must be adjusted carefully, if it is too long it can damage the bearing in the tractor's PTO or the snow blower's bearings. Also ensure good lubrication of the profile pipes. See also the instruction manual for the power transmission shaft.

Check that the power transmission shaft can be rotated by hand to ensure that it is not buckling anywhere.

Check that the power transmission shaft will not be tensioned when the machine is lifted to max. or min. height. Driving on very hilly relief, a rear-mounted snow blower can work lower or higher than the tractor itself. Please also note that the angle of the axle can be too large when using very short axles - contact the supplier - importer.



Service and maintenance

Before cleaning, lubricating, repairing or adjusting the machine, stop the engine and activate the handbrake, and remove the key during work.

Pay special attention to safety during maintenance work, park the machine in according with specified safety rules.

Inspection after screw connections

Screws - nuts - fittings and bolts on the machine should be re-tensioned after two hours of operation. All moving parts should be lubricated with grease.

The ejector spout's swivel is exposed to both cold and heavy wear - therefore use cold-resistant grease that can handle up to -40 degrees. Points 4 and 5.

Wear steel and skid pads are exposed to heavy wear - check and carry out the replacement or reversal of wear steel before damage occurs to the hull itself and mounting brackets.

Replacement of feeder blade – replacing the feeder blade, the opposite blade must be replaced also at the same time to stop vibrations.

Remove snow after use so that icing does not cause any problems at start-up later.

To extend the life of the machine, cleaning after use is recommended.

Do not flush water directly into the bearing. For long-term storage, it is recommended to lubricate the machine in acid-free oil.

Interval of lubrication and grease quality

1. Bearings for the main axle in front of fan

Interval: Monthly and when parking in the spring (approx. every 200 hours).
Avoid pushing in too much grease as this can cause sealing rings to squeeze out + contribute to overheating of the entire bearing.
Recommended amount of 7-8 grams per time.

2. Lagere for hovedaksling og flenslager bak

Interval: Monthly and when parking in the spring (approx. every 200 hours).
Avoid pushing in too much grease as this can cause sealing rings to squeeze out + contribute to overheating of the entire bearing.
The recommended amount of 7-8 grams per time.

3. Expiration spout for ball bearing

Interval: Every 50 hour.

4. Sprocket on outlet spout

Interval: When needed.

5. Power transmission shafts – universal joint + telescopic tube

Interval: Every 8 – 10 operating hour.

Maintained according to the attached instruction manual. Please contact the supplier if this is missing.

Grease quality: Universal grease of good quality.

Shear - bolt couplings

Remember to lower the machine, stop the tractor's engine and disconnect the PTO before fitting a new cutting bolt. Here are used bolts M10 qual.8.8.

Operational risks

It is the driver's responsibility not to expose himself or others to danger during the use of the snow blower. Attention should be paid to people and animals located near the machine. Since other objects occur in the snow (rocks and similar things), the throwing route must be set so that the draft snow would not be danger to other road users. Since there are more objects in the snow (stones), the ejection nozzle must be adjusted so that the ejected snow does not pose a danger to other road users.

No one should ever stand on the machine while it is driving or moving. Protective covers must always be on when it is used.

Practical use

The Norwegian Labor Inspection Authority has listed snow blowers among machines that must be used with particular care and must therefore not be operated by people without documented training. The user must have a driving license for a tractor (aged 16) and have a certificate that he has received training in the use of the machine/tool.

The machine requires skilled operation, the user manual must be read before connecting to the tractor and putting it into operation, even if the user had previous experience with a similar machine – this is for user's safety.

The top brace is adjusted so that the snow blower is parallel to the ground in working position.

Skid pads must always be used and adjusted according to the instructions in user manual.

The maximum power of PTO speed is 540 rpm. The throw length can be set by adjusting the speed.

The direct-coupled PTO must not be switched on at high rpm.

If the snow blower is pulled forward without displace the snow (punched drive shaft), you must pull back a little before re-engaging the PTO shaft.

Driving in packed snow, it is important to keep the rpm. high from the time you enter the snow until the fan is empty.

Disconnection

This happens in the reverse order of connection.

The tractor's PTO must be disconnected when working with the machine and the PTO shaft.

Place the machine on the even ground.

Disconnect hydraulic hoses.

Disconnect the power transmission shaft and hang it on a hook attachment.

Locking bolts for drawbars are released.

Now the machine is disconnected and can be left.

Declaration of conformity

Responsible person


Name: Karl Martin Eggen
Position: CEO
Company name: Duun Industrier as
Address: N-7630 Åsen
Norway
Telephone: +47 74 01 59 00

Person responsible for the technical documentation: Rolf Even Duun

Declares that the following machine: VF215 Snow blower
Manufacturer: Duun Industrier as
Type: Duun Snow blower VF215
is in accordance with:

Directive 2006/42/EC Machinery

Signed by:



Karl Martin Eggen

Åsen, 15.09.2020