

# Hydraulic switching loading while stirring. SP200

Use the drill template provided with the kit. Drill with a small drill which fits in the small hole on the drill template. Then drill the hole with a 16.5 mm drill bit.



Assemble the set and mount as in the pictures below.

