
# **BADUUN** HTS305 Mk2 Instruction manual

Duun Industrier as 7630 Åsen, Norway www.duun.no

Serial number: from HTS305-130001




Congratulations on your Duun Duun HTS305 Mk2 scraper blade.

All Duun tractor operated machines have been engineered and tested in close cooperation with representative users to produce functionally safe and user-friendly machines.

Please read this instruction manual before using the machine.

Good luck!



## **Machine identification**

Serial number and manufacturer are indicated on badge (A) Register serial number and delivery time as indicated. Always specify serial number when requesting service for the machine. The machine is CE-marked (B). This marking confirms that the machine has been manufactured in conformity with EU Directive Machinery.

Serial number

Time of delivery (month/year)


MACHINE INDETIFICATION	2
SAFETY	4
WARRANTY TERMS	<u> </u>
TECHNICAL DATA	7
SERVICE AND MAINTENANCE	9
DECLARATION OF CONFORMITY	10

## Safety

All operators, mechanics and the owner must always work carefully with agricultural machinery. Read and observe safety instructions in this instruction manual.



Be particularly aware of warning signs with this symbol, it marks measures that must be carried out in order to avoid accidents. The symbol appears in the instruction manual and on warning signs on the machine.




#### 1. Instruction manual

All operators, mechanics and the owner must be well acquainted with the instruction in this instruction manual before the machine is taken into use.




#### 2. Safety of the surroundings

Be very careful when other people or animals are near the machine or tractor. Never start the machine when there are people or animals close to it, also never stand between the tractor wheels and the machine!



#### 3. Risk of crushing during rotation

Make sure that nothing is in the range of the blade during the rotation!



#### 4. Tractor connection

Connection is made in a safe way. In case of automatic connection with triangular coupling or HMV, the hydraulic hoses are connected, and the support leg is placed in driving position before starting work. When connecting with drawbars, secure the drawbar connection with locking pins before hydraulic connection and support leg adjustment.




#### 5. Safety

Always disconnect the tractor and hydraulic functions during repairs and maintenance.



#### 6. Hydraulic high fluid pressure

Be careful when you work with hydraulics. Wear eye protection and gloves. Hydraulic oil under high pressure may penetrate the skin and cause serious infections. See a doctor if you have sustained an injury. Make sure no one is close by when performing hydraulic functions.




#### 7. Risk of crushing at marked points

Pay special attention to clamping risk at points marked for this.




#### 8. Clamping risk when adjusting

When adjusting the support wheels, make sure that you do not stand with your feet under the wear steel.



#### 9. Safe transportation

During transportation, the blade's edge is placed approximately parallel to the direction of the road to avoid sticking out and damage oncoming traffic.



#### 10. Safe transportation

Pay attention to the total length of the blade when driving/turning.



#### 11. Safe driving

During heavy use, when the main blade itself moves to the side, it can affect the steering direction of the tractor. Adjust your speed to the conditions and be aware of this moment of risk.

## Warranty terms

Duun HTS305 has 12 months guarantee against defects in materials and workmanship.

Parts that are not originally manufactured by Duun Industrier as, for example, wheels, hydraulic parts, etc. are subject to these suppliers' guarantees and terms.

In cases where a repair is considered to be covered by the guarantee, the representative must inform the supplier's representatives that the repair is intended executed based on the guarantee. In this context, the following information must be recorded:

- Product name
- The product's serial no. (see the machine identification)
- Date of sale
- The product owner's address, telephone no.

In case of such a repair, the supplier is presented with a claim within 3 weeks after the repair date.

Replaced parts are to be kept until a decision has been made with reference to the claim and the replaced parts are to be forwarded to Duun Industrier as for assessment if so required.


As the employment of the product is beyond our control, we may only guarantee the quality and do not accept liability for the product's general performance.

Duun Industrier as reserves the right to modify the design and specifications and/or make alterations and improvements without notification.

What is not included in the guarantee:

- The guarantee does not cover economic loss as a consequence of interruptions.
- The guarantee does not cover consequential loss due to defects.
- The guarantee does not cover defects or damage caused by misuse and uses that are not in accordance with the instruction manual's specifications and guidelines.

**Technical data** 



Weight 305 Height of the blade: Rotation of the main blade's edge Total boom length The main width of the blade The maximum swing angle boom The max. swing distance from center Wheel dimension Air pressure Wheel dimension Air pressure 600 kg w/hydraulics and wheels 700 mm 286 degrees 2120 mm 3050 mm. 25/20 degrees with hydraulics 2290/2170 mm with HTS 305 5.00 x 8 6- layer Max 75 lbs or 525 kpa (5,2 bar) 6.00 x 9 10- layer Max 101,5 lbs or 700kpa (7 bar)

Wear steel HTS3055

2 pcs. perforated width 1250 cm *Alternatively* 2 pcs. 200x1520 plan - 2112229


2 pcs. 193X1520 tooth - 2112233

## Service and maintenance

The hydraulic valves are set to 220 bar pressure. Changes to this are not permitted and any warranty liability is void in such a case.

After 5 hours of use - check all screw connections.

## Check all lubrication points regularly and add if it is necessary



## Declaration of conformity

### Responsible person

Name:	Karl Martin Eggen
Position:	CEO
Company name:	Duun Industrier as
Address:	N-7630 Åsen
	Norway
Telephone:	+47 74 01 59 00

Person responsible for the technical documentation: Rolf Even Duun

Declares that the following machine:	HTS305 Mk2 Scraper blade
Manufacturer:	Duun Industrier as
Туре:	Duun Scraper blade HTS305 Mk2
is in accordance with:	

Directive 2006/42/EC Machinery

Signed by:

Karl Martin Eggen Åsen, 15.09.2020