

## **Service description**

Product:	Service description	Ver:
	no	
SP200	3112-S010	1

## **Symptom**

The double gearbox at the bottom of the pump holder is loose.

## Caused by

The part of the double gearbox that points away from the tractor must NOT be completely screwed in.

## Solution

The gearbox is attached to the bracket that should fit loosely against the pump attachment. This is to avoid tension in the gearbox during start-up and moving the pump. DO NOT tighten the screw

