

Service description

| | | |
|-------------------|---|-----------|
| Product: SP400 | Service description no: 3125-S009 | Ver: 1 |
|-------------------|---|-----------|

Symptom

Slurry come out of the upper part of the cover tube towards the gearbox.



Caused by

The drainage holes in the cover tube are blocked. The cover tube is full of slurry.

Solution

Flush drainage holes.



If this does not help, the cover tube is most likely full of dried slurry.
Release the set screws on the cover tube.



Release the cover tube from the pump housing and from the gearbox housing.
Rinse cleanly inside the cover tube.