

Service description

Product:	Service description	Ver:
	No.:	
VM420	4120-S010	1

Symptom

Not enough power to move splitting knives upwards downward

Cause

- 1. Wood chips or dust have jammed the knife
- 2. The safety valves for knife movement or the control valve for the conveyor belt are incorrectly adjusted
- 3. The safety valve for the cover above splitting ram is incorrectly adjusted or does not function properly.

Løsning

- 1. Clean the casing area for the knife
- 2. Watch <u>4120-S001</u>
- 3. Watch 4120-S015